

REMINGTON®



EP7070
Use and Care Guide

Register Your New Product Today!

By registering your new Remington® product, you will receive special offers.
Register online at: RemingtonProducts.com

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance.

WARNING

To reduce the risk of burns, fire, electric shock or injury to persons:

- Close supervision is necessary when this appliance is used by, on, or near children or persons with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by manufacturer.
- Never drop or insert any object into any opening.
- Do not use this appliance with a damaged or broken epilator disc, as injury may occur.
- Always store your appliance in a moisture-free area.
- For household use only.

BATTERY SAFETY

- Remove batteries if the unit is not in use for long periods.
- It is not recommended to use a rechargeable battery.
- Do not dispose of used batteries in a fire.
- Do not short circuit the battery contacts.
- Used batteries must be removed from the appliance, recycled or disposed of in an environmentally friendly way.


SAFETY PRECAUTIONS

- Avoid using on the delicate skin around the eyes.
- DO NOT use the facial cleansing brush on the same area more than twice a day.
- DO NOT use the facial cleansing brush on areas with open wounds, sunburned skin, chapped or irritated skin.
- DO NOT use if you suffer from skin diseases or skin irritations such as severe/active acne or skin infection.
- DO NOT use if you are taking steroid-based medication.
- DO NOT use the cleansing brush with cleansers containing harsh chemicals or rough particles.
- If you wish to share this product with other users, for hygiene reasons, ensure you change the brush head. DO NOT share brush heads between multiple users.
- If you experience any pain or discomfort, stop using this product and contact your doctor.

SAVE THESE INSTRUCTIONS

PRODUCT FEATURES

Thank you for purchasing your new Remington® Ultimate Facial Hair Kit.




KEY PARTS

- | | |
|-------------------------------|---|
| 1. Facial epilator attachment | 7. Facial cleansing brush attachment |
| 2. Switch | 8. Massage attachment |
| 3. Battery compartment | 9. Brush Interface |
| 4. Comb | 10. Cleaning brush (not shown) |
| 5. Alignment marks (on rear) | 11. Epilator protective cap (not shown) |
| 6. Detail trimmer attachment | |


BEFORE FIRST USE

1. The device requires 1 'AA' battery (included).
2. Open the battery compartment by pulling the two halves of the body apart (fig. A).
3. Insert the battery into the holder with the + terminal of the battery facing down as shown (fig. B).
4. Close the battery compartment by pushing the two halves of the body together until they click.




FITTING/REMOVING ATTACHMENTS

1. To remove an attachment, twist it counterclockwise (fig. C) and pull it up and away from the body (fig. D).
2. To fit an attachment, place it over the body (fig. E) with the mark on the rim of the attachment aligned with the symbol on the body. Twist the attachment clockwise (fig. F) until the mark is aligned with the symbol.



1. The facial cleansing brush and massage attachments require the brush interface to be fitted to the motor. Fit the interface as described, then click the brush or massage head onto the interface (fig. G).



HOW TO USE

GENERAL INFORMATION ON EPILATION

The rotating tweezers catch even short hairs and pull them out by the root. The hairs that grow back are soft and thin. Epilating leaves your skin smooth and hair-free for several weeks.

If you have not used an epilator before, or if you have not epilated for a long period of time, it may take a short while for your skin to adapt to epilation. The discomfort experienced at first is considerably reduced with repeated use as the skin adjusts to the process.


Using an epilator may cause reddening or irritation of the skin. This is a normal reaction that will quickly disappear. However, you should consult your doctor if the irritation has not disappeared within three days.

All methods of hair removal from the root can result in in-growing hair depending on the condition of the skin and hair. Regular exfoliation helps to prevent in-growing hair.

In some cases inflammation of the skin could occur when bacteria penetrate the skin (e.g. when moving the appliance over the skin). Thorough cleaning of the epilation head before each use will minimise the risk of infection.

USING THE FACIAL EPILATOR

1. Fit the facial epilator attachment.
2. Turn on the device by moving the switch to the left or right depending on the desired direction of rotation.
3. Select the direction of rotation so that the hair is pulled upwards and away from the skin as the device is moved against the direction of hair growth (see figures H and J).



4. It helps if you stretch the skin gently with your free hand so that the hairs stand upright.
5. Guide the epilator with gentle pressure. Don't press too hard as this may result in injury.
- When using for the first time, it is recommended that you epilate in the evening to allow for any possible reddening to fade overnight and then to apply a moisturizer to sooth the skin.

USING THE DETAIL TRIMMER

The detail trimmer gently removes unwanted hair and is ideal for use on the face, neckline, nose, ears and other small areas.

1. Fit the detail trimmer attachment.
2. Do not apply excessive pressure, doing so may damage the trimmer head or result in skin injury.
3. Never insert the trimmer more than 6mm into nose or ear. Objects should never come into contact with the eardrum.

TO TRIM UNWANTED HAIR

1. Hold the trimmer against the skin and apply gentle pressure.
2. Trim against the direction of hair growth.

TO TRIM THE LENGTH OF THE EYEBROWS

1. Slide the eyebrow comb over the trimming head with the appropriate side of the comb facing out.

TO SHAPE THE EYEBROWS

1. Hold the detail trimmer at a right angle to your skin and press down gently.
2. Edge and shape the area as desired.

USING THE FACIAL CLEANSING BRUSH

1. Fit the brush interface and the facial cleansing brush attachment.
2. Moisten the brush bristles by running under water. DO NOT use the brush while completely dry as this can cause skin irritation.
3. Dampen your skin with water and apply cleanser onto your skin. Alternatively, apply your cleanser directly onto the brush.
4. Place the brush directly onto your skin and switch on. You can select the direction of brush rotation using the switch.
5. Gently glide the brush over the skin in circular motions avoiding the delicate eye area.
6. For best results, we recommend replacing the brush head approximately every 3 months. The brush head part number is: SP-FC18.

U.S. residents: To order accessories call 800-392-6544, visit your local retailer, or visit RemingtonProducts.com.

USING THE MASSAGER

1. Fit the brush interface and the massage attachment.
2. Place the massager directly onto your skin and switch on.
3. Gently glide the massager over the skin in circular motions.

CLEANING AND MAINTENANCE

- Ensure the device is turned off before cleaning.
- To clean the product, wipe it with a damp cloth and dry immediately.
- Facial epilator—use the supplied cleaning brush.
- Facial cleansing brush—rinse the brush after each use.
- Detail trimmer—use the supplied cleaning brush.

WARRANTY

Limited Three-Year Warranty

Empower Brands, LLC warrants this product to the original purchaser against any defects that are due to faulty material or workmanship for a three-year period from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse. If the product should become defective within the warranty period, we will replace it free of charge. Keep your sales receipt and call 800-736-4648 in the U.S. or Canada or contact us at: contactus@remingtonproducts.com for warranty information.

KEEP ORIGINAL SALES RECEIPT AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.

This warranty does not cover products damaged by the following:

- Accident, misuse, abuse or alteration of the product
- Servicing by unauthorized persons
- Use with unauthorized accessories
- Connecting it to incorrect current and voltage
- Any other conditions beyond our control

No responsibility, obligations, or liability is assumed for the installation or maintenance of this product.

EMPOWER BRANDS, LLC SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO THREE YEARS FROM DATE OF ORIGINAL PURCHASE.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province. Some states do not allow the exclusion or limitation of incidental, special or consequential damages.

This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the disputed Crimea region.

Empower Brands, LLC Money-back Offer

If within 30 days after you have purchased your Remington® branded product from an authorized source, you are not satisfied and would like a refund, return it with the sales receipt indicating purchase price and date of purchase to the retailer from whom it was purchased. Empower Brands, LLC will reimburse all retailers who accept the product within 30 days from the date of purchase. If you have any questions concerning the money-back guarantee, please call 800-736-4648 in the U.S. or Canada.

Remington Guarantees Satisfaction After 30 Days!

Remington 60-Day Money Back Guarantee*

If within 60 days after purchasing any Remington® product, you are not completely satisfied and would like a refund, keep your receipt and contact us at contactus@remingtonproducts.com or call 800-736-4648 in the U.S. or Canada.**

*Applies to U.S. and Canadian customers' returns only.

**Terms and conditions apply.

1. Refund will be in the form of a check issued in U.S. Dollars and will include applicable taxes, if any, paid by customer.
2. Please allow 4–6 weeks to receive your refund by check.

Please do not throw this product away with normal household waste. If possible, take it to an official collection point in your area that recycles this type of product. Thank you for considering the environment.

Type: EP01A

Questions or comments: Call 800-736-4648 in the U.S. or visit RemingtonProducts.com.

Dist. by: Empower Brands, LLC, Middleton, WI 53562

© registered trademark and ™ trademark of Empower Brands, LLC.
© 2024 Empower Brands, LLC. All rights reserved. 08/2024 31106

Made in China.
T22-7001106-C