REMINGTON®

Hot Rollers H-1015



Use and Care Guide

Register Your New Product Today!

By registering your new Remington® product, you will receive these important benefits: Proof of Ownership • Product Protection • Product Registration • Special Offers Register online at: www.RemingtonProducts.com

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING. KEEP AWAY FROM WATER.

DANGER

As with most electrical appliances, electrical parts are electrically live even when switch is off. To reduce the risk of death by electric shock:

- Always unplug this appliance from the electrical outlet immediately after using.
- Do not use while bathing or in the shower.
- Do not place or store this appliance where it can fall or be pulled into a tub or sink
- Do not place or drop into water or other liquid
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Unplug this appliance before cleaning it.

WARNING

To reduce the risk of burns, fire, electric shock or injury to persons:

- An appliance should never be left unattended when it is plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or persons with special needs.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water.
- Keep the cord away from the heated surfaces. Do not wrap the cord around the appliance.
- Never use while sleeping.
- Never drop or insert any object into any of the appliance's openings.


- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
- Do not use an extension cord.
- The plug on this appliance has one blade wider than the other, it is a polarized plug. As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician. Do not attempt to defeat this safety feature.
- Always store this appliance and cord in a moisture-free area. Do not store it in temperatures exceeding 140°F (60°C).
- Never block the air openings of the appliance or place it on a soft surface, such as bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, etc.
- Do not touch the roller sockets that hold the rollers. They are hot.

SAVE THESE INSTRUCTIONS



10 instant heat rollers with ions lonic technology creates negative ions, which neutralize positive ions to reduce static and the "frizzies" leaving your hair looking shiny and healthy.

- Rollers heat up in 90 seconds
- 10 lonic rollers with soft grip surface for easy rolling.
- Flame-proof, soft, lightweight case.
- Wire holders are easy to use, color coded, and hold hair in place.



How to Use

Position rollers securely onto the heating elements. Failure to do so can cause damage, including melting of the rollers.

- Close pouch and plug in unit. Rollers can be used in 90 seconds.
- . For a soft, wavy curl, use the rollers after the 90-second heat-up. For a tighter curl, use the rollers when they have reached maximum curling temperature.

1. Get Ready

Before setting, hair should be dry or only slightly damp, never wet. Section hair and comb it smooth. Roll hair as usual, in the direction of desired style, securing each roller with the proper size color-coded wire holder placed crosswise over the roller.

2. Get Set

Continue until your entire head is set. The time the rollers are left in the hair affects the tightness of the curl. The shorter the time, the softer the curl. Rollers will remain curling active approximately 15 minutes. If you wish to reuse rollers, return them to the unit and wait 90 seconds.

3. Go!

To release secured roller, remove each wire holder and roller gently. Unwind, never pull. Place roller back on correct post. Let each new curl spring back into position and cool for a moment. Then brush out hair and style. Spritz hair for extra hold



Usage Tips

Will the rollers be too hot to touch when they're completely heated? No. However, the end caps of the rollers are made of a different material. They will remain cool when the roller is heated. They are designed to be held while

rolling your hair for comfort and ease of use.

How do I know when the rollers are at the "right" temperature for curling hair?

Follow the illustration and instructions in the "HOW TO USE" section.

How long should I leave the rollers in my hair?

Again, depending on the length and texture of your hair, as well as the lightness of the curl you want, timing will vary. Feel free to experiment and have fun with vour new Reminaton® setter.

Operating and Maintenance

Operating Instructions

- 1. These heated rollers are designed to work on ordinary household current only. They are not intended for commercial use.
- 2. Plug cord into outlet, leaving pouch closed. When unit is heated, follow "How To Use" section. Unplug unit after use.
- 3. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Never try to defeat this safety feature.

CAUTION: To avoid damage, rollers must be returned to post when not in use.

Maintenance Instructions

- 1. Clean unit with damp cloth only. No other maintenance is required.
- 2. Rollers may be cleaned with a damp cloth and mild detergent or soap.
- 3. Store appliance and cord where they will not be damaged.

4. Do not wrap cord around hairsetter.

5. Do not attempt to repair the appliance yourself; return it to Remington Customer Service.

Performance Guarantee

Spectrum Brands. Inc. Money-back Offer

If within 30 days after you have purchased your Remington® branded product, you are not satisfied and would like a refund, return it with the sales slip indicating purchase price and date of purchase to the retailer from whom it was purchased. Spectrum Brands. Inc. will reimburse all retailers who accept the product within 30 days from the date of purchase. If you have any questions concerning the money-back guarantee. please call 800-736-4648 in the U.S. or 800-268-0425 in Canada.

Remington Guarantees Satisfaction After 30 Days! Remington 60-Day Money Back Guarantee*

If within 60 days after purchasing any Remington[®] product, you are not completely satisfied and would like a refund, return it with the original dated sales receipt directly to Remington and receive a full refund.** For questions concerning the money-back guarantee, please call 800-736-4648 in the US or 800-268-0425 in Canada.

*Applies to US and Canadian customers' returns only. **Terms and conditions apply.

- 1. Refund will be in the form of a check issued in US Dollars and will be provided only if all Terms and Conditions are met.
- 2. The following items must be returned to Remington and postmarked no later than 60 days after purchase of the Remington product:
 - a. The Remington product:
 - b. The original sales receipt indicating price and date purchased: and
 - c. The completed 60-day money back guarantee form located at

RemingtonProducts.com/60day.

- 3. In addition, Remington, in its discretion, must determine that the returned product was used in accordance with the instruction booklet (included with the product at the time of purchase).
- 4. Returns should be mailed prepaid (no collect returns accepted) to: Remington 60-Day MBG

507 Stokely Drive, Box 1 DeForest, WI 53532

- 5. Refund does not include postage costs for the return of the product, but will include applicable taxes paid by customer, if any.
- 6. No responsibility will be accepted for late, lost, stolen, misdirected or damaged product.
- 7. Please allow 4-6 weeks to receive your refund by check.

Warrantv

Limited Two-Year Warrantv

Spectrum Brands. Inc. warrants this product against any defects that are due to faulty material or workmanship for a two-year period from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse.

If the product should become defective within the warranty period, we will replace it free of charge. Return your product and sales receipt with your name. address and day time phone number to: Remington Returns Center, 507 Stokely Dr., P.O. Box 1, Deforest, WI 53532, For more information call 800-736-4648 in the U.S. or 800-268-0425 in Canada.

KEEP ORIGINAL SALES RECEIPT AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.

- This warranty does not cover products damaged by the following:
- Accident, misuse, abuse or alteration of the product
- Servicing by unauthorized persons
- Use with unauthorized accessories
- Connecting it to incorrect current and voltage
- Wrapping cord around appliance causing premature wear and breakage Any other conditions beyond our control

No responsibility, obligations, or liability is assumed for the installation or maintenance of this product.

SPECTRUM BRANDS, INC. SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY. ARE LIMITED IN DURATION TO TWO YEARS FROM DATE OF ORIGINAL PURCHASE.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province. Some states do not allow the exclusion or limitation of incidental, special or consequential damages

120/240 VAC 60/50 Hz

Questions or comments: Call 800-736-4648 in U.S. or 800-268-0425 in Canada or visit www.RemingtonProducts.com

® Registered trademark of Spectrum Brands, Inc. ©2015 Spectrum Brands, Inc. 2/15 Job# 12005-00 Spectrum Brands, Inc. Middleton, WI 53562 Spectrum Brands Canada. Inc. 131 Saramia Crescent, Vaughan ON L4K 4P7 Made in China. T22-29130

