

REMINGTON®

smooth&silky®

WDF4815US



Use and Care Guide

Register Your New Product Today!

By registering your new Remington® product you will receive these important benefits:
Proof of ownership • Product protection • Product registration • Special offers
Register online at: RemingtonProducts.com

Product Features

Thank you for choosing REMINGTON®. Our products are designed to meet the highest standard of quality, functionality and design. The model you have chosen can be used in or out of the shower and is designed to provide a gentle, close shave. Please read the instructions for use carefully and keep in a safe place for future reference.

CAUTION

USE THIS APPLIANCE ONLY FOR ITS INTENDED USE AS DESCRIBED IN THIS MANUAL.

DO NOT USE THIS PRODUCT IF IT IS NOT WORKING CORRECTLY, IF IT HAS BEEN DROPPED OR DAMAGED, OR DROPPED INTO WATER.

DESCRIPTION

- A. Shaving head
- B. Head release button
- C. Flexible outer foil
- D. Flexible trimmer
- E. Massaging strip
- F. On/Off switch
- G. Battery compartment
- H. Battery compartment cap
- I. Bikini trimmer headguard
- J. Cleaning brush



GETTING READY

Please be patient when first using your shaver, as with any new product, it may take a little while to familiarize yourself with the device. If you take the time to acquaint yourself with your shaver, we are confident you will receive years of enjoyable use and complete satisfaction.

INSERTING BATTERIES

Your shaver requires 2 'AAA' alkaline batteries (first set included). We recommend that you use Rayovac® batteries for optimal performance.

1. Make sure the product is turned off.
2. Rotate the battery compartment cap approximately 1/4 turn counter-clockwise and pull.
3. Insert 2 "AAA" alkaline batteries, so that the (+) and (-) symbols on the battery align with the corresponding mark in the battery compartment.
4. Place cap back on unit using the alignment marks and rotate clockwise until the cap snaps into place.

NOTE: Your shaver will not work if the batteries are inserted incorrectly.

NOTE: Remove batteries if the unit is not in use for long periods

How to Use

Your shaver is suitable for legs, underarms and the bikini area. It can be used dry or in the shower.

FOR EVERYDAY USE

1. Remove headguard.
2. Turn the shaver on.
3. Hold the shaver at a right angle to your skin and move the shaver against the direction of the hair growth.
4. After shaving, turn shaver off.

NOTE:

- The shaver IS suitable for use in the bath or shower.
- Do not rinse with water hotter than 160°F.
- Do not completely submerge the shaver in water.
- Before dry shaving, make sure that the area is clean, dry and free from creams or oils.

How to Use

FOR LONGER HAIRS

- If you have not shaved for a while, use the flexible trimmer before shaving. This will help you achieve a more effective shaving result.
1. Turn on shaver.
 2. Hold the shaver with the trimmer facing your leg and slightly tilted towards you (approximately at a 45° angle).
 3. Move the trimmer slowly against the direction of the hair growth.
 4. After shaving, turn off shaver.

TRIMMING AND SHAPING

1. Attach the bikini trimmer headguard.
2. Turn on shaver.
3. Hold the shaver at a right angle to your skin and press down gently.
4. Edge and shape the area as desired.
5. After shaving, turn off shaver.

FOR BEST SHAVING PERFORMANCE

We recommend that you use your new shaver daily for two or three weeks to allow time to find the optimum shaving methods for your particular type of hair growth patterns.

CAUTION

If your skin is easily irritated by shaving, or you suffer from skin allergies, you should test a section of your arm or leg before using the shaver.

Cleaning and Maintenance

CARE FOR YOUR SHAVER

To ensure long lasting performance of your shaver, clean the head assembly regularly. The easiest and the most hygienic way to clean the shaver is by rinsing the shaving head after use with warm water. Always keep the protective headguard on the shaving head when the shaver is not in use.

AFTER EACH USE

1. Ensure the shaver is turned off.
2. Press the release button to open the shaver head.
3. Blow on the foil to remove any loose debris.
4. Brush or rinse the accumulated hair from the main body of the shaver, shaving head and cutter assembly.
5. Leave the head assembly open to let the shaver dry completely.
6. Return the shaving head to its original position and snap in place.

NOTE:

- Ensure that the shaver is turned off when cleaning.
- Do not clean the shaving foil with the brush.
- At regular intervals, put a drop of sewing machine oil onto the foil, trimmer, and cutter head for continued performance.



REPLACING THE FOIL AND CUTTER

Signs that your foil and cutter need replacing:

- Irritation: As the foil gets worn, you may experience skin irritation.
- Pulling: As the cutter wears, your shave may not feel as close and you may feel your cutter pulling on your hair.
- Wear: You may notice that the cutter has worn through the foil.


To ensure the continued highest quality performance from your shaver, we recommend that foil and cutter are replaced every 6 months.

NOTE: The replacement part for your shaver model is **SPW-WDF48**.

To order shaver accessories, contact us at 800-392-6544 in the U.S. and Canada or visit us at RemingtonProducts.com

TO REPLACE THE FOIL

1. Ensure the shaver is switched off.
2. Remove the shaver head.
3. Gently push the small plastic tabs area at either end of the foil carrier. The foil carrier should then easily detach from the shaving head.
4. To reassemble, snap the new foil carrier into position.
5. Attach the shaving head.



CAUTION

- Only hold the plastic to prevent damage to the foil.
- Do not press on the foil when replacing.

TO REPLACE THE CUTTER

1. Ensure the shaver is switched off and open the shaving head.
2. To remove cutter, grasp cutter between thumb and forefinger and pull upward.
3. To reassemble cutter, place cutter onto oscillator tip. Gently push down clicking into position.

IMPORTANT SAFETY INSTRUCTIONS

WARNING – TO REDUCE THE RISK OF BURNS, ELECTROCUTION, FIRE, OR INJURY TO PERSONS:

Store the product at a temperature between 60°F and 95°F.

Only use the parts supplied with this appliance. Use of non Remington® parts with this product may give rise to a hazardous condition.

Keep this product out of reach of children. The use of this appliance by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge can give cause to hazards. Persons responsible for their safety should give explicit instructions or supervise the use of the appliance.

Warranty

Limited Two-Year Warranty

Spectrum Brands, Inc. is a global consumer products company with a diverse portfolio of world-class brands, including Remington®-branded electric shavers. Spectrum Brands, Inc. warrants this product against any defects that are due to faulty material or workmanship for a two-year period from the original date of

consumer purchase. This warranty does not include damage to the product resulting from accident or misuse.

If the product should become defective within the warranty period, we will replace it free of charge. Return your product and sales receipt with your name, address and day time phone number to: Remington Returns Center, 507 Stokely Dr., P.O. Box 1, DeForest, WI 53532. For more information call 800-736-4648 in the U.S. and Canada.

Warranty excludes:

- Foil and cutter

KEEP ORIGINAL SALES RECEIPT AS PROOF OF PURCHASE FOR OR WARRANTY PURPOSES.

This warranty does not cover products damaged by the following:

- Accident, misuse, abuse or alteration of the product
- Servicing by unauthorized persons
- Use with unauthorized accessories
- Any other conditions beyond our control

No responsibility, obligations, or liability is assumed for the installation or maintenance of this product.

SPECTRUM BRANDS, INC. SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO TWO YEAR FROM DATE OF ORIGINAL PURCHASE.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province. Some states do not allow the exclusion or limitation of incidental, special or consequential damages.

Performance Guarantee

Performance Guarantee

Spectrum Brands, Inc. Money-back Offer

If within 30 days after you have purchased your Remington® branded product, you are not satisfied and would like a refund, return it with the sales slip indicating purchase price and date of purchase to the retailer from whom it was purchased. Spectrum Brands, Inc. will reimburse all retailers who accept the product within 30 days from the date of purchase. If you have any questions concerning the money-back guarantee, please call 800-736-4648 in the U.S. and Canada.

Remington Guarantees Satisfaction After 30 Days!

Remington 60-Day Money Back Guarantee*

If within 60 days after purchasing any Remington® product, you are not completely satisfied and would like a refund, return it with the original dated sales receipt directly to Remington and receive a full refund.** For questions concerning the money-back guarantee, please call 800-736-4648 in the US and Canada.

*Applies to U.S. and Canadian customers' returns only.

**Terms and conditions apply.

1. Refund will be in the form of a check issued in US Dollars and will be provided only if all Terms and Conditions are met.

2. The following items must be returned to Remington and postmarked no later than 60 days after purchase of the Remington® product:

- a. The Remington® product;
- b. The original sales receipt indicating price and date purchased; and
- c. The completed 60-day money back guarantee form located at

RemingtonProducts.com/60day.

3. In addition, Remington, in its discretion, must determine that the returned product was used in accordance with the instruction booklet (included with the product at the time of purchase).

4. Returns should be mailed prepaid (no collect returns accepted) to:
Remington 60-Day MBG
507 Stokely Drive, Box 1
DeForest, WI 53532

5. Refund does not include postage costs for the return of the product, but will include applicable taxes paid by customer, if any.

6. No responsibility will be accepted for late, lost, stolen, misdirected or damaged product.

7. Please allow 4–6 weeks to receive your refund by check.

TYPE: F01A

© 2018 Spectrum Brands, Inc.
® Registered Trademark of Spectrum Brands, Inc.

7/18 22923

Questions or comments:

Call 800-736-4648 in U.S. and Canada,
or visit RemingtonProducts.com

Dist. by: Spectrum Brands, Inc., Middleton, WI 53562

Dist. by: Spectrum Brands Canada Inc.
255 Longside Drive, Unit 101
Mississauga, ON L5W 1L8

Made in China

T22-30580-B